


Wiring Diagram – early K100 RS and RT models